

Millenium Slim

Crouzet Virtual Display Guide

Smartphone Version

TABLE OF CONTENTS

	3
1. GETTING STARTED	3
1.1 – Program files to be used	3
2. CVD – Smartphone Version	3
2.1 – Connection	3
2.2 – User Interface	ł
2.3 – Connect to another controller	ł
2.4 – Update Firmware	ł
2.5 – Transfer a program	5
2.6 – Read Datalog	5
2.7 – Share Datalog / Program	5
2.8 – Read / Write Time	5
2.9 – Diagnostic	ว
Hardware	ว
Application	5
2.10 – Run / Stop	- 5
2.11 - Accessing Help	- 5
2.12 – Virtual Buttons Vibration	7
2.12 – App Version and About	7



INTRODUCTION

Welcome to the *Crouzet Virtual Display* Guide for the *MilleniumSlim* Logic Controller, this guide provides you with the foundational knowledge to be familiarized with the app environment and the different tools available. You will discover that using *Crouzet Virtual Display* with the *MilleniumSlim* logic controller is simple and straightforward.

CVD is the free Crouzet app that allows you access your controller screen and control buttons at a distance in real-time and change available parameters from any of your pc's or mobile devices:

- View & Change Parameters
- Read & write programs,
- Download datalog,
- Do firmware updates
- Run a controller diagnostic



Safe & Quick Monitoring

- Get an exact copy of your controller front screen remotely, especially in closed panel or difficult-to-access locations
- Stop your controller remotely to access your machine safely and start it once maintenance is done

Anyone can do it

- Read current datalog of your running controller and keep track of your key parameters
- Communication interruption? Program stopped? Fault detected? Make a quick diagnosis of the controller with one click



www.crouzet.com

Improve Maintenance & Make Savings:

From small changes or improvements of your program to a complete firmware update, you do not need to visit the site anymore, just send your modifications to a collaborator

Anybody can do it, either you as an expert or a designated person without risking your know-how by choosing to send a software-unreadable program

It is easier than ever without disconnecting any cable and from anywhere.



1. GETTING STARTED

Crouzet Virtual Display comes in PC version, Android Smartphone version and Apple Smartphone version. The PC version is available at the Crouzet website. While the smartphone versions are available at their respective app stores. In this guide we will cover only the Smartphone version

1.1 – Program files to be used

When you create and save a program for *MilleniumSlim* with our programming software *CrouzetSoft*, there are several files that will be created. The file with the extension ".cpcs" is the one that will be used with *Crouzet Virtual Display*: You will need to send this file to your phone and store it there, in order to transfer it later to your controller.



2. CVD – Smartphone Version

2.1 – Connection

When you first open the application, you will be asked for Bluetooth activation permission to scan the network. You need to accept in order to connect to your *MilleniumSlim*

Orange F 🖬 🦞	\$ •O• ⊿ 🔒 54 % 09:
= 😌 Virte	
	Bluetooth permission
	VIRTUAL DISPLAY is requesting permission to turn on Bluetooth.
	and another
6 B	
Orange F 🛃 🦞	3≹-O-∡ùs4%.09
	। 🗘 🖉 💰 🔅 अत्र १७: ual device: Nearby devices
	ual device: Nearby devices
	ual device: Nearby devices
	ual device: Nearby devices

All the near controllers detected will be displayed on screen. Just select the one that you want to interact with, and then select the *Connect* button.



When you are connected, *Crouzet Virtual Display* will automatically show the virtual front face of the *MilleniumSlim*, where you will be able to see the screen in real time to know the status of your application and also the 6 virtual buttons that will allow you to interact with your program.





2.2 – User Interface

This is the screen that you will see in the Smartphone version by clicking on the *Menu* button, at the left of the screen:



This is the screen that you will see in the Smartphone version if you select the *Options* button at the right of the screen, where you will be able to find the main functionalities of the app:



2.3 - Connect to another controller

If you want to disconnect from current device and connect to another controller, go to the Options button, and click on *Disconnect/Change devices*



You will be then in the *Nearby Devices* screen again to select a new controller



2.4 – Update Firmware

Sometimes you will want to update the firmware of the device, it is easy to do with **Crouzet Virtual Display**. Just select the "Update Firmware" option from the Options menu



Then you will be prompted to choose the firmware and language, once you do it you can select on *Start Update*

Orange F 🖬 🦞	💲 🛈 🔟 📓 54 % 09:1
← 😌 Virtual o	levice: SLIM8898300300008
Millenium Stim	Update firmware Please choose which immare to write into the controller. CHOOSE FIRMWARE
Connected	







2.5 – Transfer a program

This menu option allows you transfer a program (*Write*) from your phone to your *MilleniumSlim* and to retrieve (*Read*) a program from your controller to your phone



If you want to write a program, select on write and then look for the program in your phone

	Write Program
Millenium Slim	Please choose which program to write into the controller.
Connected	
	CONTINUE CHANGE PROGRAM

If you want to retrieve a program from the controller, select on read and then choose a folder in your phone to save the file.



2.6 – Read Datalog

This menu option allows you to read the datalog stored in your *MilleniumSlim*



Just choose the folder in your phone where you want to store the datalog and select continue

Orange F 🖬 🦞	* 🕩 🔺 🔒 54% 09:11
← 😌 Virtual d	levice: SLIM88983003000008
Millenium Slim	Read datalog The file will be shored in the following folder : download Change Foldoen

2.7 – Share Datalog / Program

It is possible to share a datalog or program stored in your phone to other people/devices, just select the file to share and select trough which application you want to send it.

Orange F ■ ? ← 🕞 Virt	al device: SLIM8898300300008	\$ •O ▲ 🖬 54% 09:16	
Millenium Slin • Connected	Share Datalog/Program Prese concourt the file you want to share meet race		

2.8 - Read / Write Time

It is also possible to read or change the date that your *MilleniumSlim* contains. Just click on write time and select the new date

Millenium Slim	Read/Write Time The controller time is currently :	
	24/09/20 - 14:15:25	
Connected	WRITE TIME	



← 😌 Virtual dev	24	/09/202	20 - 14:	15:25		
Millenium Slim						
Connected						

2.9 – Diagnostic

This menu option allows you to have a hardware and application diagnosis of your *MilleniumSlim*. The information that you can see is:

<u>Hardware</u>

- Type of controller
- Hardware release version
- Boot release version
- Number and type of inputs
- Number and type of outputs
- Programming type
- Controller software Release Version
- Controller status
- Error Code

In order to see all this information just scroll down in the screen



Application

- Project name
- Version
- Author
- Restricted access to "Parameters" menu
- Watchdog alive
- Basic controller cycle duration
- Password
- Application checksum
- Crouzet Software Version
- Memory used / max memory
 - o Parameters Zone (bytes)
 - Zone for digital data, SFC token and Boolean (number)
 - o Other data zones (bytes)

- Program zone (bytes)
- Zone for application-specific functions (slots)

In order to see all this information just scroll down in the screen

Orange F 🖬 💡			\$ •O• ▲ 🖬 54% 09:16
← 😌 Virtual o	evice: SLIM88983	8000008	
		APPLICATION	
Author			
Restricted access to "Pe	rameters" menu		

2.10 - Run / Stop

The RUN/STOP option is used to start and stop the controller. This option is asked automatically to the user when a function used needs to stop the controller

Orange F 🖪 🦞	¥ 🛈 🖌 🔒 54% 09	16
← 😌 Virtual	device: SLIM8898300300008	
Millenium Stim	RUN/STOP The controller is currently stopped.	
0		
Orange F 🖬 🌵	8 O P ⊿ i i 54× 09	16
	≭ ⊕ ∡ û در به device: SLIM88983003000008	16
		116

2.11 - Accessing Help

In the Smartphone version, *Help* is accessible by selecting the menu button, and then selecting on the button *"Help"*







Once you are there, you will be able to see the description of each functionality of the app.



between activate the haptic feedback or not

	nge F 🖬 🦞	🕷 🕩 🔟 🖬 54% 09:16
-	🗄 😌 Preferences	
	Haptic Feedback /Ibrate when using the keys	•
\cup		

buttons of the controller. To do this, just select *Preferences* in the *Menu* button, and then choose

2.12 – App Version and About

You can see the app version information in the *About* option that you can find in the *Menu* button.



2.12 - Virtual Buttons Vibration

For better interaction with the app, it is possible to activate or deactivate the vibration of the virtual

